

# GPS-Manuals-Public



## Frequently Asked Questions for the GPS Fleet Software

### Online UserManual

Study our online documentation for a better understanding.

### Contact our support

Contact to our technical support

### Content of the UserManual

- General
  - Alarms and Events - General Definition
  - Legal standard terms and imprint
  - Requirements
  - Software Releases
  - User Management & Drivers (operators, users, drivers)
- Features
  - Login-Page
  - Start Page Overview
  - Asset Configuration
  - Asset List
  - Logbook Module
  - Reports in the GPS Fleet Software
  - Options Module
  - Geofence Module
  - JSON API
  - Masterdata (drivers, geofences, users, ...)
  - Persons / Drivers
  - History Feature
  - E-Mail Module for Automatic Email Reports
  - CabCash API
  - Email Reports
- Additional Features
  - File Data archive (optional)
  - Fuel Bill Interface [optional]
  - Garmin FMI Working with a Garmin Navigation Device (optional)
  - GPS Municipal Services for winter service and salt spreaders (charge-able)
  - IOT Tankmatix Sensor Data (optional)
  - IVMS Driver-Rating System (in-vehicle monitoring system) for safe driving
  - Optimization Module (optional, chargeable, free in testing phase)
  - Sending Orders to Drivers (Smartphones or Tablets) - optional
  - Smartphone Access Link from Mobile Phone (optional)

### Installation manual

- General Instructions
- GPS Installation App Tests and Documentation
- Installation Manual Fleet-15/20 (Teltonika FMB630 / FMBB640 / FM6320)
- Installation Manual Fleet-10 (Teltonika FM5300)
- Installation Manual Heavy-10 (Teltonika FM1204)
- Troubleshooting RMA
- Installation Manual Car-10 (Teltonika FM22,FM42, FM41, FM11)
- Accessories (CANBUS, RS232, ...)
  - FMS Data (CANBUS from Fleet Management Standard interface) for trucks
  - Winter Service Spreader Connection (RS232 )
- Installation-Manual Tankmatix Fuel Level Sensor
- Older manuals
  - Installation Manual AK1
  - Installation Manual ETI Fuel Securing Module
  - Installation Manual Garmin
  - Installation Manual Squarell
- Installation Manual AT5i
- Installation Manual AT1 Pro

- Tour Module (optional, charge-able) to create journey-plans / send / optimize tours
- IT-Administration
  - JSON API Interface (optional)
  - Server-Requirements for Installing the GPS Fleet Software Server (only server clients)
  - Support